

RTA

CABINET STORE

March 24, 2026

Primary Grey Shaker Kitchen Cabinets Price List



Sink base

Model #	Item	Price
EG-CSF42	Primary Grey Shaker Corner Sink Front for 42" Space - 27" W	\$202.93
EG-SB30	Primary Grey Shaker Sink Base Cabinet - 30" W x 34.5" H	\$366.00
EG-SB33	Primary Grey Shaker Sink Base Cabinet - 33" W x 34.5" H	\$387.72
EG-SB36	Primary Grey Shaker Sink Base Cabinet - 36" W x 34.5" H	\$398.27
EG-SB42	Primary Grey Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$456.92
EG-VSB36	Primary Grey Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$545.04
EG-VSB42	Primary Grey Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$603.52
EG-VSB48	Primary Grey Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$674.30

Filler

Model #	Item	Price
EG-FF396	Primary Grey Shaker Fluted Filler - 3" W x 96" H	\$141.52
EG-OLF330	Primary Grey Shaker Overlay Filler - 3" W x 30" H	\$49.71
EG-OLF336	Primary Grey Shaker Overlay Filler - 3" W x 36" H	\$57.89
EG-OLF342	Primary Grey Shaker Overlay Filler - 3" W x 42" H	\$66.66
EG-OLF630	Primary Grey Shaker Overlay Filler - 6" W x 30" H	\$100.02
EG-F396	Primary Grey Shaker Filler - 3" W x 96" H	\$78.35
EG-F696	Primary Grey Shaker Filler - 6" W x 96" H	\$157.31

End panel

Model #	Item	Price
EG-DWR3	Primary Grey Shaker Dish Washer End Panel	\$168.44
EG-BPLG4896	Primary Grey Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$276.01
EG-OP3353	Primary Grey Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$207.64
EG-TEP3096	Primary Grey Shaker Tall End Panel	\$296.49
EG-PSP4896	Primary Grey Shaker 1/2" Thick Finished Plywood Panel	\$459.67

Molding

Model #	Item	Price
EG-RCM8	Primary Grey Shaker Royal Crown Molding	\$208.79
EG-OCM8	Primary Grey Shaker Outside Corner Molding	\$36.84
EG-SHOE	Primary Grey Shaker Shoe Molding	\$29.83
EG-SCM8	Primary Grey Shaker Shaker Crown Molding	\$98.26
EG-BCM8	Primary Grey Shaker Large Crown Molding	\$200.61
EG-BEM8	Primary Grey Shaker Bottom Edge Molding (Narrow Light Rail)	\$100.02
EG-BAM8	Primary Grey Shaker Batten Molding	\$29.26
EG-FBM8	Primary Grey Shaker Furniture Base Molding	\$138.01
EG-CM8	Primary Grey Shaker Traditional Crown Molding	\$98.26
EG-COM8	Primary Grey Shaker Cove Crown Molding	\$164.36

Blind door

Model #	Item	Price
EG-BB36	Primary Grey Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$483.06
EG-BB42	Primary Grey Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$547.39
EG-BB48	Primary Grey Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$602.36
EG-BW3636	Primary Grey Shaker Blind Wall Cabinet - 36" W x 36" H	\$387.72
EG-BW3642	Primary Grey Shaker Blind Wall Cabinet - 36" W x 42" H	\$486.85

Pantry

Model #	Item	Price
EG-P1884	Primary Grey Shaker Pantry - 18" W x 84" H	\$756.17
EG-P1890	Primary Grey Shaker Pantry - 18" W x 90" H	\$815.81
EG-P1896	Primary Grey Shaker Pantry - 18" W x 96" H	\$849.13

Oven

Model #	Item	Price
EG-OC3390	Primary Grey Shaker Oven Cabinet - 33" W x 90" H	\$1,230.02
EG-OC3396	Primary Grey Shaker Oven Cabinet - 33" W x 96" H	\$1,313.92
EG-OCD337	Primary Grey Shaker Oven Cabinet Drawer	\$318.51

Deep

Model #	Item	Price
EG-W361824	Primary Grey Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$339.62
EG-W362424	Primary Grey Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$394.77

Single door

Model #	Item	Price
EG-W930	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 30" H	\$146.05
EG-W936	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 36" H	\$165.41
EG-W942	Primary Grey Shaker Single Door Wall Cabinet - 9" W x 42" H	\$196.49
EG-W1230	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 30" H	\$167.77
EG-W1236	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 36" H	\$188.86
EG-W1242	Primary Grey Shaker Single Door Wall Cabinet - 12" W x 42" H	\$225.21
EG-W1530	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 30" H	\$187.69
EG-W1536	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 36" H	\$216.43
EG-W1542	Primary Grey Shaker Single Door Wall Cabinet - 15" W x 42" H	\$256.33
EG-W1830	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 30" H	\$215.26
EG-W1836	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 36" H	\$245.19

EG-W1842	Primary Grey Shaker Single Door Wall Cabinet - 18" W x 42" H	\$292.11
EG-W2130	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 30" H	\$240.49
EG-W2136	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 36" H	\$273.91
EG-W2142	Primary Grey Shaker Single Door Wall Cabinet - 21" W x 42" H	\$325.55
EG-VB15	Primary Grey Shaker Single Door Base Vanity - 15" W x 21" D	\$293.58
EG-VB18	Primary Grey Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$316.40
EG-B09	Primary Grey Shaker Single Door Full Height Base Cabinet - 9" W	\$210.56
EG-B12	Primary Grey Shaker Single Door Standard Base Cabinet - 12" W	\$289.76
EG-B15	Primary Grey Shaker Single Door Standard Base Cabinet - 15" W	\$316.15
EG-B18	Primary Grey Shaker Single Door Standard Base Cabinet - 18" W	\$340.81
EG-B21	Primary Grey Shaker Single Door Standard Base Cabinet - 21" W	\$368.36

Double door

Model #	Item	Price
EG-B24-2	Primary Grey Shaker Double Door Standard Base Cabinet - 24" W	\$407.06
EG-B27	Primary Grey Shaker Double Door Standard Base Cabinet - 27" W	\$502.68
EG-B30	Primary Grey Shaker Double Door Standard Base Cabinet - 30" W	\$516.77
EG-B33	Primary Grey Shaker Double Door Standard Base Cabinet - 33" W	\$561.33
EG-B36	Primary Grey Shaker Double Door Standard Base Cabinet - 36" W	\$573.06
EG-V24-2	Primary Grey Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$280.11
EG-V27	Primary Grey Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$326.92
EG-V30	Primary Grey Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$338.60
EG-V33	Primary Grey Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$371.95
EG-V36	Primary Grey Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$394.75
EG-W2430-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 30" H	\$286.27
EG-W2436-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 36" H	\$333.75
EG-W2442-2	Primary Grey Shaker Double Door Wall Cabinet - 24" W x 42" H	\$385.35
EG-W2730	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 30" H	\$319.69
EG-W2736	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 36" H	\$361.34
EG-W2742	Primary Grey Shaker Double Door Wall Cabinet - 27" W x 42" H	\$429.34
EG-W3012	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 12" H	\$149.58
EG-W3015	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 15" H	\$185.36
EG-W3018	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 18" H	\$239.32
EG-W3024	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 24" H	\$293.28
EG-W3030	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 30" H	\$330.26
EG-W3036	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 36" H	\$391.23
EG-W3042	Primary Grey Shaker Double Door Wall Cabinet - 30" W x 42" H	\$464.57
EG-W3315	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 15" H	\$202.37
EG-W3330	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 30" H	\$368.36
EG-W3336	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 36" H	\$420.00
EG-W3342	Primary Grey Shaker Double Door Wall Cabinet - 33" W x 42" H	\$497.97
EG-W3612	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 12" H	\$185.36
EG-W3615	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 15" H	\$207.06
EG-W3618	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 18" H	\$275.10
EG-W3630	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 30" H	\$381.87
EG-W3636	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 36" H	\$448.71
EG-W3642	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 42" H	\$532.60
EG-W3918	Primary Grey Shaker Double Door Wall Cabinet - 39" W x 18" H	\$293.28
EG-W3924	Primary Grey Shaker Double Door Wall Cabinet - 39" W x 24" H	\$353.09
EG-W3624	Primary Grey Shaker Double Door Wall Cabinet - 36" W x 24" H	\$329.07

Model #	Item	Price
EG-LSB36	Primary Grey Shaker Lazy Susan Cabinet - 36" W x 24" D	\$1,036.76

Easy reach

Model #	Item	Price
EG-ER36	Primary Grey Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$611.19

Drawer base

Model #	Item	Price
EG-DB12-3	Primary Grey Shaker Drawer Base Cabinet - 12" W	\$438.16
EG-DB15-3	Primary Grey Shaker Drawer Base Cabinet - 15" W	\$484.51
EG-DB18-3	Primary Grey Shaker Drawer Base Cabinet - 18" W	\$520.29
EG-DB21-3	Primary Grey Shaker Drawer Base Cabinet - 21" W	\$556.64
EG-DB24-3	Primary Grey Shaker Drawer Base Cabinet - 24" W	\$594.77
EG-DB30-3	Primary Grey Shaker Drawer Base Cabinet - 30" W	\$678.64
EG-VDB12	Primary Grey Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$429.23
EG-VDB15	Primary Grey Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$464.33
EG-VDB18	Primary Grey Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$500.02
EG-VDB21	Primary Grey Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$559.65
EG-VDB24	Primary Grey Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$619.31

Wine Rack

Model #	Item	Price
EG-WR3018	Primary Grey Shaker Wine Rack - 30" W x 18" H x 12" D	\$261.41

Other

Model #	Item	Price
EG-SPRAYCAN	Primary Grey Shaker Spray Can	\$11.69
EG-TBUNFOOT	Primary Grey Shaker Bunfoot	\$116.96
EG-TBUNFOOT2	Primary Grey Shaker Transitional Bunfoot	\$116.96
EG-TKS8	Primary Grey Shaker Toe Kick	\$25.17
EG-TPOSTP3	Primary Grey Shaker Turned Post - 3" W x 35.5" H	\$210.52
EG-TPOSTP5	Primary Grey Shaker Turned Post - 5" W x 35.5" H	\$321.03
EG-TUKIT	Primary Grey Shaker Touchup Kit	\$54.24
EG-LRM8	Primary Grey Shaker Traditional Light Rail	\$200.61
EG-SCRIBE	Primary Grey Shaker Scribe	\$31.57
EG-SHELF1296	Primary Grey Shaker Shelf - 96" W x 12" D	\$274.28
EG-CORMSM	Primary Grey Shaker Basic Medium Corbel - 10.5" H	\$56.15
EG-CORT	Primary Grey Shaker Transitional Corbel	\$155.58
EG-CORT Box5	Primary Grey Shaker Transitional Medium Corbel - 10.5" H	\$111.11
EG-CW2430	Primary Grey Shaker Corner Wall Cabinet - 24" W x 30" H	\$358.98
EG-CW2436	Primary Grey Shaker Corner Wall Cabinet - 24" W x 36" H	\$402.97
EG-CW2442	Primary Grey Shaker Corner Wall Cabinet - 24" W x 42" H	\$510.92
EG-CW2736	Primary Grey Shaker Corner Wall Cabinet - 27" W x 36" H	\$460.47
EG-CW2742	Primary Grey Shaker Corner Wall Cabinet - 27" W x 42" H	\$546.68
EG-BBP4842	Primary Grey Shaker Bead Board - 48" W x 42" H x 0.25" D	\$155.58
EG-BCE1596	Primary Grey Shaker Book Case End - 1.5" W x 96" H x 15" D	\$226.89