

RTA

CABINET STORE

March 24, 2026

Primary White Shaker Kitchen Cabinets Price List



Sink base		
Model #	Item	Price
EW-CSF42	Primary White Shaker Corner Sink Front for 42" Space - 27" W	\$202.93
EW-SB30	Primary White Shaker Sink Base Cabinet - 30" W x 34.5" H	\$366.00
EW-SB33	Primary White Shaker Sink Base Cabinet - 33" W x 34.5" H	\$387.72
EW-SB36	Primary White Shaker Sink Base Cabinet - 36" W x 34.5" H	\$398.27
EW-SB42	Primary White Shaker Sink Base Cabinet w/ CS - 42" W x 34.5" H	\$456.92
EW-VSB36	Primary White Shaker Vanity Sink Base - 36" W x 34.5" H x 21" D	\$545.04
EW-VSB42	Primary White Shaker Vanity Sink Base - 42" W x 34.5" H x 21" D	\$603.52
EW-VSB48	Primary White Shaker Vanity Sink Base - 48" W x 34.5" H x 21" D	\$674.30
Filler		
Model #	Item	Price
EW-FF396	Primary White Shaker Fluted Filler - 3" W x 96" H	\$141.52
EW-OLF330	Primary White Shaker Overlay Filler - 3" W x 30" H	\$49.71
EW-OLF336	Primary White Shaker Overlay Filler - 3" W x 36" H	\$57.89
EW-OLF342	Primary White Shaker Overlay Filler - 3" W x 42" H	\$66.66
EW-OLF630	Primary White Shaker Overlay Filler - 6" W x 30" H	\$100.02
EW-F396	Primary White Shaker Filler - 3" W x 96" H	\$78.35
EW-F696	Primary White Shaker Filler - 6" W x 96" H	\$157.31
End panel		
Model #	Item	Price
EW-DWR3	Primary White Shaker Dish Washer End Panel	\$168.44
EW-BPLG4896	Primary White Shaker Back Panel (Long Grain) - 48" W x 96" H x 1/4" Thick	\$276.63
EW-OP3353	Primary White Shaker Oven Cabinet Overlay Panel - 33" W x 55" H	\$207.64
EW-TEP3096	Primary White Shaker Tall End Panel	\$296.49
EW-PSP4896	Primary White Shaker 1/2" Thick Finished Plywood Panel	\$459.67

Molding

Model #	Item	Price
EW-RCM8	Primary White Shaker Royal Crown Molding	\$208.79
EW-OCM8	Primary White Shaker Outside Corner Molding	\$36.84
EW-SHOE	Primary White Shaker Shoe Molding	\$29.83
EW-SCM8	Primary White Shaker Shaker Crown Molding	\$98.26
EW-BCM8	Primary White Shaker Large Crown Molding	\$200.61
EW-BEM8	Primary White Shaker Bottom Edge Molding (Narrow Light Rail)	\$100.02
EW-BAM8	Primary White Shaker Batten Molding	\$29.26
EW-FBM8	Primary White Shaker Furniture Base Molding	\$138.01
EW-CM8	Primary White Shaker Traditional Crown Molding	\$98.26
EW-COM8	Primary White Shaker Cove Crown Molding	\$164.36

Blind door

Model #	Item	Price
EW-BB36	Primary White Shaker Blind Base Cab for 36" to 39" Space - 30" W	\$483.06
EW-BB42	Primary White Shaker Blind Base Cab for 42" to 45" Space - 36" W	\$547.39
EW-BB48	Primary White Shaker Blind Base Cab for 48" to 51" Space - 48" W	\$602.36
EW-BW3636	Primary White Shaker Blind Wall Cabinet - 36" W x 36" H	\$387.72
EW-BW3642	Primary White Shaker Blind Wall Cabinet - 36" W x 42" H	\$486.85

Pantry

Model #	Item	Price
EW-P1884	Primary White Shaker Pantry - 18" W x 84" H	\$756.17
EW-P1890	Primary White Shaker Pantry - 18" W x 90" H	\$815.81
EW-P1896	Primary White Shaker Pantry - 18" W x 96" H	\$849.13

Oven

Model #	Item	Price
EW-OC3390	Primary White Shaker Oven Cabinet - 33" W x 90" H	\$1,230.02
EW-OC3396	Primary White Shaker Oven Cabinet - 33" W x 96" H	\$1,313.92
EW-OCD337	Primary White Shaker Oven Cabinet Drawer	\$318.51

Deep

Model #	Item	Price
EW-W361824	Primary White Shaker Deep Wall Cabinet - 36" W x 18" H x 24" D	\$339.62
EW-W362424	Primary White Shaker Deep Wall Cabinet - 36" W x 24" H x 24" D	\$394.77

Single door

Model #	Item	Price
EW-W930	Primary White Shaker Single Door Wall Cabinet - 9" W x 30" H	\$146.05
EW-W936	Primary White Shaker Single Door Wall Cabinet - 9" W x 36" H	\$165.41
EW-W942	Primary White Shaker Single Door Wall Cabinet - 9" W x 42" H	\$196.49
EW-W1230	Primary White Shaker Single Door Wall Cabinet - 12" W x 30" H	\$167.77
EW-W1236	Primary White Shaker Single Door Wall Cabinet - 12" W x 36" H	\$188.86
EW-W1242	Primary White Shaker Single Door Wall Cabinet - 12" W x 42" H	\$225.21
EW-W1530	Primary White Shaker Single Door Wall Cabinet - 15" W x 30" H	\$187.69
EW-W1536	Primary White Shaker Single Door Wall Cabinet - 15" W x 36" H	\$216.43
EW-W1542	Primary White Shaker Single Door Wall Cabinet - 15" W x 42" H	\$256.33
EW-W1830	Primary White Shaker Single Door Wall Cabinet - 18" W x 30" H	\$215.26
EW-W1836	Primary White Shaker Single Door Wall Cabinet - 18" W x 36" H	\$245.19

EW-W1842	Primary White Shaker Single Door Wall Cabinet - 18" W x 42" H	\$292.11
EW-W2130	Primary White Shaker Single Door Wall Cabinet - 21" W x 30" H	\$240.49
EW-W2136	Primary White Shaker Single Door Wall Cabinet - 21" W x 36" H	\$273.91
EW-W2142	Primary White Shaker Single Door Wall Cabinet - 21" W x 42" H	\$325.55
EW-VB15	Primary White Shaker Single Door Base Vanity - 15" W x 21" D	\$293.58
EW-VB18	Primary White Shaker Single Door Base Vanity-18"W x 34.5"H x 21"D	\$316.40
EW-B12	Primary White Shaker Single Door Standard Base Cabinet - 12" W	\$289.76
EW-B09	Primary White Shaker Single Door Full Height Base Cabinet - 9" W	\$210.56
EW-B15	Primary White Shaker Single Door Standard Base Cabinet - 15" W	\$316.15
EW-B18	Primary White Shaker Single Door Standard Base Cabinet - 18" W	\$340.81
EW-B21	Primary White Shaker Single Door Standard Base Cabinet - 21" W	\$368.36

Double door

Model #	Item	Price
EW-B24-2	Primary White Shaker Double Door Standard Base Cabinet - 24" W	\$407.06
EW-B27	Primary White Shaker Double Door Standard Base Cabinet - 27" W	\$502.68
EW-B30	Primary White Shaker Double Door Standard Base Cabinet - 30" W	\$516.77
EW-B33	Primary White Shaker Double Door Standard Base Cabinet - 33" W	\$561.33
EW-B36	Primary White Shaker Double Door Standard Base Cabinet - 36" W	\$573.06
EW-V24-2	Primary White Shaker Double Door Vanity - 24" W x 34.5" H x 21"	\$280.11
EW-V27	Primary White Shaker Double Door Vanity - 27" W x 34.5" H x 21"	\$326.92
EW-V30	Primary White Shaker Double Door Vanity - 30" W x 34.5" H x 21"	\$338.60
EW-V33	Primary White Shaker Double Door Vanity - 33" W x 34.5" H x 21"	\$371.95
EW-V36	Primary White Shaker Double Door Vanity - 36" W x 34.5" H x 21"	\$394.75
EW-W2430-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 30" H	\$286.27
EW-W2436-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 36" H	\$333.75
EW-W2442-2	Primary White Shaker Double Door Wall Cabinet - 24" W x 42" H	\$385.35
EW-W2730	Primary White Shaker Double Door Wall Cabinet - 27" W x 30" H	\$319.69
EW-W2736	Primary White Shaker Double Door Wall Cabinet - 27" W x 36" H	\$361.34
EW-W2742	Primary White Shaker Double Door Wall Cabinet - 27" W x 42" H	\$429.34
EW-W3012	Primary White Shaker Double Door Wall Cabinet - 30" W x 12" H	\$149.58
EW-W3015	Primary White Shaker Double Door Wall Cabinet - 30" W x 15" H	\$185.36
EW-W3018	Primary White Shaker Double Door Wall Cabinet - 30" W x 18" H	\$239.32
EW-W3024	Primary White Shaker Double Door Wall Cabinet - 30" W x 24" H	\$293.28
EW-W3030	Primary White Shaker Double Door Wall Cabinet - 30" W x 30" H	\$330.26
EW-W3036	Primary White Shaker Double Door Wall Cabinet - 30" W x 36" H	\$391.23
EW-W3042	Primary White Shaker Double Door Wall Cabinet - 30" W x 42" H	\$464.57
EW-W3315	Primary White Shaker Double Door Wall Cabinet - 33" W x 15" H	\$202.37
EW-W3330	Primary White Shaker Double Door Wall Cabinet - 33" W x 30" H	\$368.36
EW-W3336	Primary White Shaker Double Door Wall Cabinet - 33" W x 36" H	\$420.00
EW-W3342	Primary White Shaker Double Door Wall Cabinet - 33" W x 42" H	\$497.97
EW-W3612	Primary White Shaker Double Door Wall Cabinet - 36" W x 12" H	\$185.36
EW-W3615	Primary White Shaker Double Door Wall Cabinet - 36" W x 15" H	\$207.06
EW-W3618	Primary White Shaker Double Door Wall Cabinet - 36" W x 18" H	\$275.10
EW-W3630	Primary White Shaker Double Door Wall Cabinet - 36" W x 30" H	\$381.87
EW-W3636	Primary White Shaker Double Door Wall Cabinet - 36" W x 36" H	\$448.71
EW-W3642	Primary White Shaker Double Door Wall Cabinet - 36" W x 42" H	\$532.60
EW-W3918	Primary White Shaker Double Door Wall Cabinet - 39" W x 18" H	\$293.28
EW-W3924	Primary White Shaker Double Door Wall Cabinet - 39" W x 24" H	\$353.09
EW-W3624	Primary White Shaker Double Door Wall Cabinet - 36" W x 24" H	\$329.07

Lazy susan

Model #	Item	Price
EW-LSB36	Primary White Shaker Lazy Susan Cabinet - 36" W x 24" D	\$1,036.76

Easy reach

Model #	Item	Price
EW-ER36	Primary White Shaker Easy Reach Base Cabinet - 36" W x 24" D	\$611.19

Drawer base

Model #	Item	Price
EW-DB12-3	Primary White Shaker Drawer Base Cabinet - 12" W	\$438.16
EW-DB15-3	Primary White Shaker Drawer Base Cabinet - 15" W	\$484.51
EW-DB18-3	Primary White Shaker Drawer Base Cabinet - 18" W	\$520.29
EW-DB21-3	Primary White Shaker Drawer Base Cabinet - 21" W	\$556.64
EW-DB24-3	Primary White Shaker Drawer Base Cabinet - 24" W	\$594.77
EW-DB30-3	Primary White Shaker Drawer Base Cabinet - 30" W	\$636.32
EW-VDB12	Primary White Shaker Vanity Drawer Base - 12" W x 34.5" H x 21"	\$429.23
EW-VDB15	Primary White Shaker Vanity Drawer Base - 15" W x 34.5" H x 21"	\$464.33
EW-VDB18	Primary White Shaker Vanity Drawer Base - 18" W x 34.5" H x 21"	\$500.02
EW-VDB21	Primary White Shaker Vanity Drawer Base - 21" W x 34.5" H x 21"	\$559.65
EW-VDB24	Primary White Shaker Vanity Drawer Base - 24" W x 34.5" H x 21"	\$619.31

Wine Rack

Model #	Item	Price
EW-WR3018	Primary White Shaker Wine Rack - 30" W x 18" H x 12" D	\$261.41

Other

Model #	Item	Price
EW-SPRAYCAN	Primary White Shaker Spray Can	\$11.69
EW-TBUNFOOT	Primary White Shaker Bunfoot	\$116.96
EW-TBUNFOOT2	Primary White Shaker Transitional Bunfoot	\$116.96
EW-TKS8	Primary White Shaker Toe Kick	\$25.17
EW-TPOSTP3	Primary White Shaker Turned Post - 3" W x 35.5" H	\$210.52
EW-TPOSTP5	Primary White Shaker Turned Post - 5" W x 35.5" H	\$321.03
EW-TUKIT	Primary White Shaker Touchup Kit	\$54.24
EW-LRM8	Primary White Shaker Traditional Light Rail	\$200.61
EW-SCRIBE	Primary White Shaker Scribe	\$31.57
EW-SHELF1296	Primary White Shaker Shelf - 96" W x 12" D	\$274.28
EW-CORMSM	Primary White Shaker Basic Medium Corbel - 10.5" H	\$55.57
EW-CORT	Primary White Shaker Transitional Corbel	\$155.58
EW-CW2430	Primary White Shaker Corner Wall Cabinet - 24" W x 30" H	\$358.98
EW-CW2436	Primary White Shaker Corner Wall Cabinet - 24" W x 36" H	\$402.97
EW-CW2442	Primary White Shaker Corner Wall Cabinet - 24" W x 42" H	\$510.92
EW-CW2736	Primary White Shaker Corner Wall Cabinet - 27" W x 36" H	\$460.47
EW-CW2742	Primary White Shaker Corner Wall Cabinet - 27" W x 42" H	\$546.68
EW-BBP4842	Primary White Shaker Bead Board - 48" W x 42" H x 0.25" D	\$155.58
EW-BCE1596	Primary White Shaker Book Case End - 1.5" W x 96" H x 15" D	\$226.89